

File Version Control (Cross Copy) Operation Change Updated 10/29/14

Important Note:

Both the eDARTs and the eDART Data Manager **REQUIRE** updated software. 1) Install the eDART Software Update (Version 9.4 or 10.6.6 on each eDART. 2) Install the eDART Data Manager Software Update (Version 2.6.1) on the EDM.

The 9.4 and 10.6.6 software updates improves the robustness of the file sharing between the eDARTs and the EDM. The updates also has a built in file corruption scan to help prevent problems.

- 1) **File Corruption Detection:** Each eDART is equipped with file corruption detection software. If corruption is detected, a warning message will be displayed to the user. The message will inform the user that corruption has been detected and that Cross Copy to and from this eDART has been terminated.

- 2) **File Sharing Limits:** Cross Copy for critical files, e.g. Templates, Alarm Settings and Controls have not been changed. These files still get copied to the eDART Data Manager as the changes occur.

Security Configuration: Security configuration must be deployed to the EDM and eDARTs with a single manual step. After setting up security, choose to copy the security configuration to the eDART Data Manager. The security changes will then be copied to the eDART Data Manager. The security changes will be sent to each eDART automatically.

Color and Curve Configuration: Curve and graph color configuration must be deployed to the EDM and eDARTs with a single manual step. After selecting curve and graph colors, go to the Main Menu and choose to copy the settings to the eDART Data Manager. The settings will be copied to the other eDARTs when the particular job is no longer running.