



## INSTALLATION

Refer to product manual for all installation dimensions and instructions—available for download online at [www.rjginc.com](http://www.rjginc.com).

1 OR2-M—Lynx Shielded Dual-Relay Output Module

2 C-OR2-M-3M—Lynx Shielded Dual-Relay Output Module Cable (x2)

3 Machine Input Card or Robot†

4 ID7-M-SEQ or DIN/LX-M—Lynx Shielded Sequence Module or Lynx Communications Adapter

5 CE-LX5-W—Lynx Premium Cable

6 J-LX1—Lynx Single Feed-Through Junction

7 CE-LX5-W—Lynx Premium Cable

8 eDART or CoPilot System

† wiring installation depends upon desired use and connected equipment.

